

ACCUVOTE

Date / Time Settings

**Power on the machine while depressing the YES and NO buttons.
This puts you in DIAGNOSTIC MODE.**

The display should read SET SYSTEM CLOCK ... ANSWER YES

**The date will be displayed and you will be askedIS DATE OK?
Answer YES or NO accordingly to the following questions until desired
date is reached.**

**The system time is displayed and you will be asked.... .IS TIME OK?
Answer YES or NO accordingly.to the following questions until desired
time is reached.**

**Once you see "*DUMP MEMORY CARD IMAGE*".
At this point, just shut the machine off.**

*Please call if you have any questions and one of us can assist you.
1-888-LHS-VOTE*